



All Calibration Steps B-EX6

For Reflective Calibration

For Transmissive Calibration

RESET PRINTER

Maintenance Counter Clear

1. Press and hold **FEED & PAUSE** keys and turn ON the printer, should display **[SYSTEM MODE]**
2. Use directional arrow to cursor to **[RAM CLEAR]** and press the **ENTER** key
3. Cursor down to **[MAINTE. CNT CLEAR]** and press the **ENTER** key
4. At the **[ALL COUNTER]** setting, press the **ENTER** key
5. At the **COMPLETED** message, power the printer OFF

QM Parameter Clear

1. Press and hold **FEED & PAUSE** keys and turn ON the printer, should display **[SYSTEM MODE]**
2. Use directional arrow to cursor to **[RAM CLEAR]** and press the **ENTER** key
3. Cursor down to **[PARAMETER CLEAR]** and press the **ENTER** key
4. At the **[QM TYPE]** setting, press the **ENTER** key
5. At the **COMPLETED** message, power the printer OFF

AUTO CALIBRATION

Turn ON Auto Calibration for **TRANSMISSIVE**

1. Press and hold **FEED & PAUSE** keys and turn ON the printer, should display **[SYSTEM MODE]**
2. Use directional arrow to cursor to **[SET PARAMETERS]** and press the **ENTER** key
3. Cursor down to **[CALIBRATE]** and press the **ENTER** key
4. Cursor down to **[ON TRANSMISSIVE]** and press the **ENTER** key
5. At the **[CALIBRATE]** setting, power the printer OFF

Turn ON Auto Calibration for **REFLECTIVE**

1. Press and hold **FEED & PAUSE** keys and turn ON the printer, should display **[SYSTEM MODE]**
2. Use directional arrow to cursor to **[SET PARAMETERS]** and press the **ENTER** key
3. Cursor down to **[CALIBRATE]** and press the **ENTER** key
4. Cursor down to **[ON REFLECTIVE]** and press the **ENTER** key
5. At the **[CALIBRATE]** setting, power the printer OFF

Turn **OFF** Auto Calibration

1. Press and hold **FEED & PAUSE** keys and turn ON the printer, should display **[SYSTEM MODE]**
2. Use directional arrow to cursor to **[SET PARAMETERS]** and press the **ENTER** key
3. Cursor down to **[CALIBRATE]** and press the **ENTER** key
4. Cursor up to **[OFF]** and press the **ENTER** key
5. At the **[CALIBRATE]** setting, power the printer OFF



MANUAL CALIBRATION

TRANSMISSIVE Manual Sensor Calibration

1. Press and hold **FEED & PAUSE** keys and turn ON the printer, should display [**SYSTEM MODE**]
2. Use directional arrow to cursor to [**SENSOR**] and press the **ENTER** key
3. Cursor down to [**ADJUSTMENT**] and press the **ENTER** key
4. Cursor down to [**TRANSMISSIVE SENSOR**] setting, press the **ENTER** key
5. Remove enough labels to expose the liner and place the liner under both of the sensors.
6. Hold **ENTER** until asterisk shows to the right of digits.
7. Press **ENTER** 1x and power printer OFF

REFLECTIVE Manual Sensor Calibration

1. Press and hold **FEED & PAUSE** keys and turn ON the printer, should display [**SYSTEM MODE**]
2. Use directional arrow to cursor to [**SENSOR**] and press the **ENTER** key
3. Cursor down to [**ADJUSTMENT**] and press the **ENTER** key
4. At the [**REFLECTIVE SENSOR**] setting, press the **ENTER** key
5. Place plastic labels under sensor. Calibrate for the darkest color. Usually red.
6. Hold **ENTER** until asterisk shows to the right of digits. (Should read 4.0 ± 0.3 volt range)
7. Press **ENTER** 1x and power printer OFF

PAPER END Calibration

1. Press and hold **FEED & PAUSE** keys and turn ON the printer, should display [**SYSTEM MODE**]
2. Use directional arrow to cursor to [**SENSOR**] and press the **ENTER** key
3. Cursor down to [**ADJUSTMENT**] and press the **ENTER** key
4. Cursor down to [**PAPER END LEVEL**] setting, press the **ENTER** key
5. Remove labels from printer, no material under the sensor.
6. Hold **ENTER** until asterisk shows to the right of digits.
7. Press **ENTER** 1x and power printer OFF

RIBBON Sensor Calibration

1. Press and hold **FEED & PAUSE** keys and turn ON the printer, should display [**SYSTEM MODE**]
2. Use directional arrow to cursor to [**SENSOR**] and press the **ENTER** key
3. Cursor down to [**ADJUSTMENT**] and press the **ENTER** key
4. Cursor down to [**RIBBON SENSOR**] and press the **ENTER** key
5. Hold **ENTER** until asterisk shows to the right of digits. (Should read in the 0.7V range)
6. Press **ENTER** 1x and power printer OFF

THRESHOLD REFLECTIVE Calibration with Pause button

1. Press **PAUSE** 1x. LCD will show **PAUSE**.
2. Hold **PAUSE** until LCD shows [**SELECT MEDIA SENSOR**], then release.
3. At the [**REFL. (PRE-PRINT)**] setting, press the **ENTER** key
4. At the [**THRESHOLD MODE**] setting, hold **PAUSE**. Tags will feed. Allow several tags to feed, then release **PAUSE**.
5. Press **ENTER** key 1x and then **RESTART** key 1x to put the printer back online.



THRESHOLD TRANSMISSIVE Calibration with Pause button

1. Press PAUSE 1x. LCD will show PAUSE.
2. Hold PAUSE until LCD shows [SELECT MEDIA SENSOR], then release.
3. At the [TRANS. (PRE-PRINT)] setting, press the ENTER key
4. At the [THRESHOLD MODE] setting, hold PAUSE. Tags will feed. Allow several tags to feed, then release PAUSE.
5. Press ENTER key 1x and then RESTART key 1x to put the printer back online.

OTHER SETTINGS

HEAD CHECK

1. Press and hold FEED & PAUSE keys and turn ON the printer, should display [SYSTEM MODE]
2. Use directional arrow to cursor to [DIAGNOSTIC] and press the ENTER key
3. Cursor down to [HEAD CHECK] and press the ENTER key to check the print-head condition.

*NORMAL END = head is good and has no broken elements.

*HEAD ERROR = broken elements on the printers head.

STONE ADJUST Darkness Setting

1. Press and hold FEED & PAUSE keys and turn ON the printer, should display [SYSTEM MODE]
2. Use directional arrow to cursor to [SET PARAMETERS] and press the ENTER key
3. Cursor down to [TONE ADJ. <T>] and press the ENTER key
4. Use the UP & DOWN arrow to change the darkness setting and press ENTER
5. At the [TONE ADJ. <T>] setting, cycle power the printer

Z-MODE (Zebra Language) ON

1. Press and hold FEED & PAUSE keys and turn ON the printer, should display [SYSTEM MODE]
2. Use directional arrow to cursor to [EMULATION MODE] and press the ENTER key
3. Cursor down to [Z MODE ON] and press the ENTER key
4. At the [EMULATION MODE] setting, cycle power the printer.

D-MODE (Datamax Language) ON

1. Press and hold FEED & PAUSE keys and turn ON the printer, should display [SYSTEM MODE]
2. Use directional arrow to cursor to [EMULATION MODE] and press the ENTER key
3. Cursor down to [D MODE ON] and press the ENTER key
4. At the [EMULATION MODE] setting, cycle power the printer.

EMULATION MODE OFF

1. Press and hold FEED & PAUSE keys and turn ON the printer, should display [SYSTEM MODE]
2. Use directional arrow to cursor to [EMULATION MODE] and press the ENTER key
3. Cursor down to [OFF] and press the ENTER key
4. At the [EMULATION MODE] setting, cycle power the printer.